



21530 – Rhino Grip Rack/Handle Bar Mount

ITEM	DESCRIPTION	QTY	Spare P/N
1	PLASTIC BASE ASSEMBLY	2	71508
2	CLIP	2	71509
3	RHINO GRIP	2	
4	RUBBER STRAP	2	87010
5	¼" – 20 X 1.50" TRUSS HEAD BOLT	4	
6	¼" - 20 NYLOC NUT	4	
7	RUBBER ATTACHMENT PAD	2	71510



2.



3.



7.



8.

MOUNTING INSTRUCTIONS:

1. First, position the grips at the location or your choice and mark the spot.
2. Place the Nyloc Nuts into the Hex cut outs on the Base Assembly, and set aside within reach. Be sure your Main Base Assembly is also within reach.
3. Wrap the Rubber Attachment Pad around the rack or handle bar.
4. Take the Base Assembly with the Nuts already inserted and hold the rubber pad.
5. Next, take the Main Base Assembly and place on the other side of the tubing.
6. Place the Truss Head Bolts supplied through the main Base Assembly and into the Nyloc Nuts, being careful not to push the nuts out. Use your finger to cover the nut to prevent it from falling out.
7. Tighten the Base Assembly together, making sure that you tighten the hardware equally. Do not over tighten!
8. Place the Grip into the Base Assembly making sure to engage the splines. Secure by sliding the Clip through the slot until you here it snap into place. NOTE: Insert the clip into the smooth side of the base ONLY or damage can occur!

Note: Heavier items should not be carried with the grip in the FULL-TILT position or damage can occur! For a custom fit, the grip can be trimmed with a sharp knife.